

PeractoJet™

High Performance Ink for digital printing on fabrics



High-performance ink set for single-pass or multi-pass printing.

Water-based Nano Pigment Dispersions for textile printing.

Typical pre and post treatments may be reduced or eliminated.

PeractoJet Technology:

PeractoJet inks contain nano-sized pigment particles, which easily color textile substrates.

When heating the textile to 285°F (140°C), PeractoJet Inks form a long chain molecule that attaches to the nano pigments and binds them to the textile substrate.

Once fixation is complete, the pigments are attached to the textile substrate.

One single PeractoJet Ink can be used for polyamide, polyester and cotton fabrics.

- Short fixation time.
- One-Ink system for all textile fibers.
- May eliminate traditional pre-treatment.
- Reduced water consumption (except for machine cleaning).
- No steam needed.

Disclaimer

Information contained in this technical data sheet is up-to-date and correct to the best of Organic Dyes & Pigments' knowledge at the date of issue and are subject to change. As Organic Dyes & Pigments LLC cannot control or anticipate the conditions under which this product may be used, each user should review the information in specific context of the planned use. Organic Dyes & Pigments will not be responsible for damages of any nature resulting from the use or reliance upon the information contained in this data sheet. No express or implied warranties are given.

Released: 09/19 RY

Technical Specifications

For all colors	PeractoJet L	PeractoJet M	PeractoJet H
Viscosity (at 28°C)	4.0 – 5.5 cps	8.0-9.0 cps	13.0 – 14.0 cps
Static Surface tension (at 28°C)	34-36 mN/m	34-36 mN/m	34-36 mN/m
Shelf life (from production date)	1 year	1 year	1 year

Application of PeractoJet™ Inks

WARNING: PeractoJet™ inks and ink products of other manufacturers are not compatible with each other. Prevent intermixing as this will most certainly damage the print heads!

Follow the manufacturer's instructions on the safe and proper operation of the printer hardware, ink purging operation, and ink changeover routine.

Special Preparation of the printer for PeractoJet™ inks

1. Remove the old existing ink.
2. Rinse with the existing cleaner.
3. Rinse with clean, filtered, deionized/distilled water.
4. Replace in-line filters and tubes if possible.
5. Use **Farbenpunkt Cleaner WB** to rinse the entire fluid path from ink container and through print heads.
6. Fill in PeractoJet™ Inks.

What to consider for the printing process

1. The printing heads should be equipped with a capping system which is activated at a machine stop. If not available, the machine shall be left on at and idle/standby state to allow periodic exercise and cleaning.
2. Tests and trial applications including 140°C fixation and proper conditioning are necessary to determine the final color profile.

Storage & Handling of PeractoJet™ products

Store between 5°C and 25°C in closed bottles/bins.

Protect from frost and store away from direct sunlight.

Keep partially filled container completely closed.

Prevent excessive agitation of partially filled containers and the incorporation of air outside of normal handling.

Information contained in this technical data sheet is up-to-date and correct to the best of Organic Dyes & Pigments' knowledge at the date of issue and are subject to change. As Organic Dyes & Pigments LLC cannot control or anticipate the conditions under which this product may be used, each user should review the information in specific context of the planned use. Organic Dyes & Pigments will not be responsible for damages of any nature resulting from the use or reliance upon the information contained in this data sheet. No express or implied warranties are given. Released: 09/19 RY