

OrcoAluminum™ Grey OL

OrcoAluminum™ Grey OL is a medium shade true Grey, with a slight blue hue and excellent lightfastness.

Features:

- RoHS compliant
- Stable color
- Metalized Azo dye
- Minimal bleeding during sealing
- pH Stabilized chemistry



Operating Parameters:

Concentration: 1 to 3 g/l
pH: 5.3 to 5.8
pH Adjustment: With dilute 10% conc. acetic acid or sodium hydroxide
Temperature: 130°F to 150°F
Time: 1 to 3 min

Operating Procedures

Maintain pH and concentration for color reproducibility from load to load. A dilute nitric acid rinse of 5 to 10% at ambient temperature will produce uniform color.

Handling and Environmental

This is a metalized dye containing chromium. Please handle in accordance with local regulations.

Dye Bath Analysis

1. Use a fixed wave Spectrophotometer and set to the wavelength of 1570 nm
2. Make known standards of regular concentration, 50% below that number and 50% above that number in grams/liter
3. Pipette 5 ml of each of the standard into 1000 ml volumetric flask
4. Read the transmission vales of each of the know standards
5. Plot a curve using the transmittance values and the corresponding concentration
6. Pipette a 5 ml sample of the process dye bath and dilute to 1000 ml in a volumetric flask
7. Read the transmittance of the dye and using the graph plotted above determine the concentration of the dye.

Actual dye samples must be evaluated in a laboratory in the chemical system or medium in which they are to be used for accurate shade and physical property results. Shades shown on print material and computer monitors are for general reference only as they are inherently inaccurate due to calibration variations and technical limitations of monitors and printers. Revised 01/20 RY